

**Attention :** Eye protection must always be used when operating this machine for your safety

**Power Supply :** This Tire Truer requires input voltage between 6 & 12 volts and minimum of 5 amps

Abrasive patches supplied are self adhesive. Peel & stick to affix to the sanding plate

Periodically oil motor bushings to maximize drive motor life

Always oil bushings or bearings on the slot car axle when in use before truing

**NEVER** Attempt to true axle without bushings or bearings or wear to the V blocks will cause permanent damage

Visit [www.professormotor.com](http://www.professormotor.com) to view the instructional videos for best results. Happy Truing !

