



PROFESSOR MOTOR CONTROLLERS

Thanks for purchasing the “Commercial Track Rental” Electronic Controller PMTR2106 (replaces 2046/2103)
Intended application : 1/24 commercial track racing through 16D and JK Falcon. Not recommended for Group 12 / Group 15 or high-powered glue racing

This model features the following high quality features

- **Recommended operating voltage range 12 to 15 volts DC**
- Wired for **POSITIVE** polarity tracks (not for direct connection to home set power base)
- Electronic “Platinum Series” transistor design with wide range of control
- Dual circuit breaker fault tolerant robust circuit design to protect against overload or short circuit damage
- Fully functional in 2 wire (non-brake) applications
- Extra long, heavy duty 13 gage super flexible, high temp silicone controller leads
- Solid copper alligator clips with color coded vinyl insulating boots
- High impact polycarbonate plastic molded handle, Stainless steel hardware throughout
- Low friction silver alloy wiper button with ultra hard nickel plated contact surface

Use & Care Instructions

- **Caution ! : Regular maintenance is required** to keep the controller contacts clean and free from foreign objects & debris. Failure to properly clean, lube and maintain the contacts will cause the controller to fail, will allow the car to be driven without the throttle being depressed. Please take this warning seriously and follow this process to keep the contacts clean & properly lubricated :
 1. **Remove the front half of the controller case by loosening the three bolts**
 2. **Clean all debris from the nickel-plated contacts and surrounding area with a Q-Tip and lighter fluid**
 3. **The sliding contacts MUST be CAREFULLY lubricated to reduce contact wear and provide a smoother controller action. To lube, do so as follows :**
 - a. **Place a **SMALL** amount of Super Lube PTFE lube on the end of a Q-Tip & apply to the nickel contacts in the area where the silver alloy contact travels**
 - b. **Cycle the trigger a few times**
 - c. **Use a Q-Tip with lighter fluid to remove any excess lube outside of the area where the contacts meet (remove 90% of the lube you just applied)**
 - d. **Examine the contact area to insure that cotton fibers from the Q-Tip are removed and that residual lube is minimal & barely visible**
 4. **Repeat this cleaning / lube process on a frequent basis (every 1-2 weeks) for best results.**
- Periodic Maintenance – lube the trigger pivot bushing with plastic compatible oil

For technical information, questions or the latest catalog of available service parts and upgrades please visit us on the World Wide Web : www.professormotor.com